

ROKOAT RPX3000 AutoOne

Overview

This product is designed for professional use. However following these instructions closely will enable most users to achieve premium results.

Safety Notes

Use in well ventilated areas.

Protective gloves and safety glasses must be worn at all times.

Health, safety and environmental information are provided for this product in the Materials Safety Data Sheet (MSDS). This gives details of potential hazards, precautions and First Aid measures, together with environmental effects and disposal of used products.

Application Methods

Brush / Roller Spray Micro-Fibre

Sponge

Professional Application only.

* Detailed application methods can be found in the Product Application Guide.

Applicable Surfaces

All types of vehicles – cars, buses, trucks, trams & trains. Anyway where protection and reduction in maintenance is required.

Surface Preparation

- Thoroughly wash your vehicle using a pH neutral shampoo with NO additives such as waxes or silicones.
- Use an iron-removing agent to clean metal areas from rust spots. This should be left for a few minutes before rinsing thoroughly.
- Carefully inspect the surface for tree sap or tar spots – remove with Tar & Glue remover. Rinse well.
- Decontaminate surface to be treated using a Clay Bar and lubricant to achieve a smooth to the touch surface.
- Dry the vehicle thoroughly.
- Polish surface with a rotary polishing system.
 - Stage One – Compound
 - Stage Two – Finishing achieving maximum gloss minus swirls, holograms or haze.
- Prep surface using an oil and polish with 50% IPA (Isopropyl Alcohol to Water), mist the paint and wipe down with a clean micro-fibre.

Product Preparation

- Gently agitate the product – DO NOT SHAKE THE BOTTLE.

Application Methodology

MicroFibre

- Apply coating by hand using a microfibre, soft sponge or applicator block with a suedine cloth.
- Allow 30-90 seconds to flash off (lines and bubbles will appear, time dependant on temperature)
- Buff with 2 clean micro-fibre cloth, leaving a brilliant and slick finish.

Curing & Secondary Coatings

Certain surfaces will require multiple coats to ensure full characteristic performance. Please confirm with Rokoat how many coats will be required.

If applying a second coat do so no longer than 30 minutes after first application.

Follow application process.

Leave to cure for 12-24 hours BEFORE exposing to exterior elements.

DO NOT wash vehicle for 10 days. The coating will continue to cure reaching its maximum hardness (9H) during this time.